

Warranty & Support

This product is provided with a one year warranty for problems found during normal usage. Mistreating the Bee-Bot Docking Station or opening the unit will invalidate this warranty.

All out of warranty repairs will be subject to a replacement fee.

Technical Support

Please visit www.tts-group.co.uk for the latest product information.

Email feedback@tts-group.co.uk for technical support.

TTS Group Ltd.
Park Lane Business Park
Kirkby-in-Ashfield
Nottinghamshire,
NG17 9GU, UK.

Freephone: 0800 318686 Freefax: 0800 137525

TTS is proud to be part of **RM** plc

Bee-Bot[®] Docking Station

WARNING: Do not dispose of this product in household waste. Hand it over to a collection point for recycling electronic appliances.

WARNING! Not suitable for children under 36 months due to small parts – choking hazard. Made in China, on behalf of the TTS Group Ltd.



TTS Product Code:
EL00145



Bee-Bot[®] Docking Station

Easy to carry, wall mountable



USER GUIDE



The Bee-Bot Docking Station is not only easy to carry and move around, but is also an excellent storage device – it's even wall mountable (fixtures not included). The Docking Station houses up to 6 rechargeable Bee-Bots and the Bee-Bots are easily recharged by plugging the Docking Station into a mains power supply.

Important Information

Please read all instructions carefully before using.

Please retain the packaging and these instructions for future reference.


- Do not allow your Bee-Bot Docking Station to come into contact with water or other liquids.

Contents

Important Information	2
Know Your Bee-Bot Docking Station	3
Recharging Your Bee-Bot	3
Troubleshooting	5
Power Supply Specification	5
Warranty & Support	6

Bee-Bot[®] Docking Station

Know Your Bee-Bot Docking Station




Recharging Your Bee-Bots

The Bee-Bots are recharged by inserting them into the Docking Station and plugging the Docking Station into the mains, using the mains power adapter included. Up to 6 Bee-Bots may be charged at the same time in the Docking Station.



International Charger

The Bee-Bot Docking Station is supplied with a multi-region adaptor. The adaptor is supplied with the UK plug fitted but you can change this easily to suit any country. Press the release button and slide the UK plug out and replace with the required plug module. Slide the plug module in until it “clicks” in place securely.



The safety isolating transformer to be used with the Docking Station should be regularly examined for potential hazards such as damage to the cable, cord, plug, enclosure or other parts. In the event of any damage, the Docking Station must not be used until the damage has been properly repaired.



- The Docking Station is not intended for children under 3 years old.
- The transformer is not a toy.
- The Docking Station must only be used with the recommended transformer.

Bee-Bot[®] Docking Station

Power Supply Specification

The Bee-Bot Docking Station is designed to work reliably and predictably in normal conditions. However, it is possible that problems may occur. Please check the following before contacting technical support:

Feature	Specification
Input Voltage	100 – 240V a.c.
Frequency	50 – 60 Hz
Standby power	0.3W (Max)
Output Voltage	5.5V d.c. \pm 5%
Output Current	3000mA (Max)
Output power	7.5W

Troubleshooting

Problem	Solution
Power LED does not light	Check that the mains adaptor is connected and the mains outlet is switched on.
I cannot fit the Bee-Bot into the Docking	Make sure that the Bee-Bot is facing outwards. Make sure that the Bee-Bot is the rechargeable version
The Bee-Bots do not charge	Ensure that the power LED is on and that all Bee-Bots are switched off whilst charging.